



IMMEDIATE ACTIONS

- **Leave** the contaminated room and go into the open air.
- **For first aid, wear** a self-contained breathing apparatus or, if not possible, a suitable full cartridge mask (ABEK EN 14387 type).
- **Open the windows** and set the fume hood (sorbonne) to its maximum flow rate.
- **Consult a doctor urgently** even without any symptoms (identify the product, CAS number, SDS).
- **In case of massive inhalation, call:**
 - SAMU (15 or 112),
 - Firefighters (18),
 - By SMS for the deaf and hard of hearing (114).

IN ANY CASE

- Declare the accident (medical certificate required).
- Inform your **safety manager** immediately.
- All injuries are to be reported using the **occupational health and safety logbook**.
- Report all incidents to the **Occupational Health Doctor** for investigation and follow-up.

PROTECTION MEASURES

- It is essential to **handle** volatile gases and toxic substances under a **fume hood** (sorbonne).
- **Wear protective glasses** with side shields, suitable gloves and a closed gown.
- **Wear an FFP3 mask**, use hooded scales for weighing fine powders, away from air movements and away from passages.
- **Have a face mask with cartridge(s)** suitable and in good condition for handling very toxic gases and volatile products.